



Programming instructions for 3 button Ford 3 button remote

1. **Obtain all remotes** for the vehicle
2. Sit in vehicle with all **doors closed but not locked**
3. Switch the **ignition from OFF to ON 4 times** within 10 seconds
4. On the 4th turn ensure that **key remains in the OFF** position
5. Programming mode is now activated
6. Within 10 seconds – **press and release any button on the first remote & repeat for all remotes to be programmed**
7. Once all remotes have been programmed **switch ignition to ON position or wait 10 seconds**
8. Programming mode is now de-activated

A maximum of 4 remotes can be programmed into the vehicle using this procedure.

| | | |
|---|---|--|
|  |  |  |
| FOR-NWKS3 (4C) | FOR-NWKS4 (4D 60) | FOR-NWKS15 (4D 63) |